



jp.ik
inspiring knowledge



TRIGONOXN01

The new era of modular computing

TRIGONO XN01 is a convertible laptop based on Intel's NUC Elements. The Element, a compact and powerful technology, consists in a module which includes the CPU, memory and Wi-Fi. This module can be easily replaced or transferred into a different device, offering a new ecological approach to computing. It also allows to choose the configuration which best fits the needs of the user, whether it's a device for a student, a teacher or a on the go professional.





Flexible

Enables the upgrading of NUC Elements while maintaining the same chassis, or switch to a different chassis while keeping the same NUC Elements. Choose from 7 different NUC Elements and storage options.

Sustainable

This modular approach allows to extend the device's lifecycle drastically while promoting the reduction of technological waste, offering a new ecological approach to computing.

Repairable

If the barebone gets damaged, the user can switch to a different one in a matter of minutes, without losing any data or apps. If NUC Elements Module fails, the user can replace the module – there will not be a loss of data in case it has an external SSD. The keyboard and battery are easily replaceable.

Barebone Specifications

Storage • 128GB/ 256GB/ 512GB PCIe SSD (NVMe) (Optane Supported)

Display • 15.6" IPS FHD 300nits / 4K (UHD) 500nits; Multi-touch w/ Active Stylus support

I/O • 2x USB 3.0 Type-C; 2x USB 3.0 Type-A; 1x HDMI; 1x Micro-SD Card Slot; 1x Combo Audio Jack; 1x RJ45

Battery • 45Wh Li-Po Battery

Sensors • Fingerprint; Ambient light sensor; Gyroscope; 2x G-Sensor

Camera • 1MP

Dimensions • 368 x 258 x 23.35mm

Weight • <2.5kg

NUC Elements Specifications

Intel® Celeron™ 4305U + 4GB LPDDR4 + 64GB eMMC + AC9560

Intel® Pentium™ 5405U + 4GB LPDDR4 + 64GB eMMC + AC9560

Intel® Core™ i3-8145U + 4GB LPDDR4 + AC9560

Intel® Core™ i5-8265U + 8GB LPDDR4 + AC9560

Intel® Core™ i5-8365U + 8GB LPDDR4 + AC9560

Intel® Core™ i7-8565U + 8GB LPDDR4 + AC9560

Intel® Core™ i7-8665U + 8GB LPDDR4 + AC9560

The information contained in this product brochure may change without notice.

For more information, please contact: sales@jpik.com | www.jpik.com